dreamon

Omeh

PREMIUM COMPACT MASSAGER

사용설명서

모델 DROM02

사용하기 전에
설명서를 읽어 주세요.

OMEH



01 제품 구성과 조작

전원 버튼
길게 눌러 켜고 끄기


상태 표시등
강도, 압력, 배터리 상태 표시

Type-C 포트
본체 상단 충전 단자

강도 변경
작동 중 전원 버튼을 짧게 누르세요.

과압 보호 후 작동 재개
전원 버튼을 짧게 누르세요.

마사지 헤드 교체



기본으로 장착된 헤드는 평면형입니다.

기본 구성품 본체, 마사지 헤드(3개), USB 충전 케이블, 전용 파우치, 사용설명서

02 상태 표시등

마사지 강도 흰색 점등	약~중	중	강	뷰티 모드
마사지 압력 분홍색 점등	약한 압력	가벼운 압력	중간 압력	강한 압력
과압 / 배터리 부족 빨간색 점멸	과압 보호	배터리 부족		
충전 상태 흰색 점멸	25% 미만	25~60%	60~90%	90~100%

뷰티 모드는 초저강도입니다. 사용 금지 부위는 03 항목을 확인하세요.

압력이 너무 강하면 잠시 멈춥니다. 잠시 후 자동으로 다시 작동합니다.
전원 버튼을 짧게 눌러 재개할 수도 있습니다. 배터리가 부족하면 충전하세요.

○○○○ 충전 완료 시 흰색 표시등 4개가 계속 켜집니다.

03 사용 전 확인과 제품 사양

사용 금지 부위
머리, 얼굴, 목 앞부분(경동맥), 척추, 관절, 뼈가 돌출된 부위에 직접 사용하지 마세요.

사용 금지 대상
임산부, 심장질환자(인공심박기 착용자 포함), 골다공증 환자, 디스크 등 척추 질환자, 영유아 및 어린이는 사용하지 마세요.

사용 시간
한 부위에 10분 이상 연속 사용하지 마세요. 10분 자동 종료 후 최소 10~15분 휴식을 권장합니다. 사용 중 불편하면 즉시 중단하세요.

제품명 / 모델	휴대용 마사지건 / DROM02
정격 입력 / 배터리	DC 5 V / 10 W · 800 mAh
제품 크기	약 93.5 × 83.5 × 39 mm (길이 × 너비 × 높이)
자동 종료 / 충전	10분 / 90분
KC인증번호	R-R-dR8-DROM

04 충전과 보관

경고 고속충전기 사용 금지

반드시 정격 출력 5 V / 2 A 이하의 일반 충전 어댑터를 사용하세요.
9 V 또는 12 V 등 5 V를 초과하는 고속충전기와
USB-C to C 방식의 PD 충전은 사용하지 마세요.
회로 손상, 발열 또는 고장의 원인이 될 수 있습니다.
이로 인한 고장은 무상 A/S 대상에서 제외됩니다.

충전 시 주의
충전 중에는 제품을 켜거나 사용하지 마세요. 충전이 끝나거나 충전 중 정전이 발생하면 충전기를 콘센트에서 뽑으세요.

보관과 관리
욕실 등 습한 곳에 보관하지 마세요. 화기와 직사광선을 피하고, 여름철 차량 내부에 두지 마세요. 장기간 사용하지 않을 때는 방전을 막기 위해 2~3개월에 한 번 충전하세요. 청소 전에는 전원을 끄고 마른 천으로 닦으세요.

05 문제 해결과 보증

문제 해결
전원이나 표시등이 켜지지 않으면 충전 상태와 연결을 확인하세요. 전원을 끈 뒤 3초 이상 기다렸다가 다시 켜세요. 작동 중 멈추거나 속도가 느리면 배터리 잔량을 확인하세요. 과열되면 사용을 중단하고 충분히 식히세요. 문제가 계속되면 고객센터로 문의하세요.

보증 기간 구입일로부터 1년
소비자 부주의로 인한 파손 · 침수, 고속충전기 사용으로 인한 기판 소손, 임의 분해 또는 개조로 인한 고장은 무상 보증에서 제외되며 유상으로 수리합니다.

고객센터(A/S) 접수처 1844-0877
www.omeh.co.kr

dreamon

Omeh

PREMIUM COMPACT MASSAGER

User Manual

Model DROM02

Read this manual
before use.

OMEH



01 Parts and Controls

Power button
Press and hold to turn on or off

Status Indicators
Intensity, pressure and battery

USB-C port
Charging port on top of the unit

Adjust intensity
Press the power button briefly while the unit is running.

Resume after overpressure
Press the power button briefly.

Changing the Massage Head



The flat head comes preinstalled.

In the box Main unit, 3 massage heads, USB charging cable, pouch, user manual

02 Status Indicators

Intensity Steady white	Low–medium	Medium	High	Beauty mode

Beauty mode uses very low intensity. See section 03 for areas to avoid.

Pressure Steady pink	Low	Light	Medium	High

Red alerts Flashing red	Overpressure	Low battery

The unit pauses when pressure is too high and resumes automatically after a short pause. You can also press the power button briefly to resume. Recharge when the battery is low.

Charge level Flashing white	Below 25%	25~60%	60~90%	90~100%

○○○○ All four white lights stay on when charging is complete.

03 Safety and Specifications

Areas to avoid

Do not use directly on the head, face, front of the neck (carotid arteries), spine, joints or bony areas.

Who should not use this product

Do not use during pregnancy or with heart disease, a pacemaker, osteoporosis, a herniated disc or another spinal condition. Do not use on infants or children.

Session limits

Use for less than 10 minutes per area. After automatic shutoff at 10 minutes, rest for 10–15 minutes before resuming. Stop if you feel discomfort.

Product / Model	Portable massage gun / DROM02
Input / Battery	DC 5 V / 10 W · 800 mAh
Dimensions	Approx. 93.5 × 83.5 × 39 mm (L × W × H)
Auto shutoff / Charge	10 min / 90 min
KC registration No.	R-R-dR8-DROM

04 Charging and Storage

WARNING Do not use fast chargers

Use only a standard 5 V adapter rated at 2 A or less.
Do not use fast chargers that output more than 5 V (such as 9 V or 12 V), or use USB-C to USB-C PD charging. This can damage the circuitry, cause overheating or lead to product failure. The warranty does not cover failures caused by improper charging.

Charging precautions

Do not turn on or use the unit while charging. Unplug the charger when charging is complete or if power goes out during charging.

Storage and care

Avoid damp places such as bathrooms, open flames and direct sunlight. Do not leave the unit in a hot car. If stored for long periods, recharge every 2–3 months to prevent deep discharge. Switch off before cleaning with a dry cloth.

05 Troubleshooting and Warranty

Troubleshooting

If the unit or indicator lights do not turn on, check the charge level and cable connection. Wait at least 3 seconds after switching off before turning it back on. If it stops or slows down, check the battery. If it overheats, stop using it and let it cool. Contact customer service if the issue persists.

Warranty One year from purchase

Paid repair applies to damage from mishandling or water exposure, circuit board damage caused by fast charging, and faults caused by unauthorized disassembly or modification.

Customer service and repairs 1844-0877
www.omeh.co.kr